


Modify a target time


This article explains how to modify the target of a product or a phase in a specific line.

Step-by-step guide

Go to the *Configuration Multi Unit OEE Administration* page



Select the line you wish to update and go to the *Targets* tab



Select the product using the *Product dropdown*.

You will see all the equipments the product is available and you will be able to set up the standard duration of the batch and of each phase (if available).

