

BW - QM - Inspection Results by Lot (Core Query)

Description	BW - QM - Inspection Results by Lot (Core Query)
Technical Name	BW_QRY_MVQM01_0002 Migrate to BW_QRY_CPQM02_0011
Application	QM
Info-provider	MVQM01
Usage type	Direct Execution
Expected users	


- [Workbook/Query General Description](#)
- [General parameters](#)
 - [Global properties](#)
 - [Variables](#)
 - [Definitions](#)
 - [Variable Sequence](#)
- [Filters](#)
- [Key figures](#)
- [Characteristics](#)
- [Cells](#)
- [Conditions](#)
- [Exceptions](#)

Workbook/Query General Description

This query is a simple view of QM Inspection Results general and quantitative data.

General parameters

Global properties

Tab	Screenshot	Comment
Display	 The screenshot shows two sections of a configuration window. The 'Display Options' section has three checkboxes: 'Adjust Formatting after Refreshing' (checked), 'Hide Repeated Key Values' (checked), and 'Display Scaling Factors for Key Figures' (unchecked). The 'Document Links' section has three checkboxes: 'For InfoProvider Data' (unchecked), 'For Master Data' (unchecked), and 'For Metadata' (unchecked).	

Rows/Columns	Result Position Rows ☐ Above ☒ Below Columns ☐ Left ☒ Right Suppress Zeros Suppress Zeros ☒ Do Not Suppress ☐ Active ☐ Active (All Values = 0) Effect on ☒ Rows ☐ Columns ☐ Rows and Columns <table><tr><td>10</td><td>10</td><td>0</td><td>20</td></tr><tr><td>10</td><td>-10</td><td>0</td><td>0</td></tr><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>20</td><td>0</td><td>0</td><td>20</td></tr></table>	10	10	0	20	10	-10	0	0	0	0	0	0	20	0	0	20	
10	10	0	20															
10	-10	0	0															
0	0	0	0															
20	0	0	20															
Value Display	Display of +/- Signs ☒ Before the Number -123.45 ☐ After the Number 123.45- ☐ In Parentheses (123.45) Zero Value Display Display Zeros Zero with Curren Show Zeros As...																	
Planning	Startup View ☐ Start Query in Change Mode Calculation of Inverse Formulas Selecting the checkbox results in calculation of inverse formulas if an element in the formula group has been changed or fixed. Otherwise, the calculation is not performed until the value of input-ready formula has been changed or fixed. Calculation Mode ☐ Symmetrical Calculation Mode for Inverse Formulas																	

Extended	Enterprise ID	
	AKLI1L2RFQC0SKPRUCKBG2B1A	
	Release for External Access	
	Allow External Access to this Query	
	☐ By OLE DB for OLAP	
	Lightweight consumption	
☐ By Easy Query		
Request Status		
Every InfoProvider in MultiProvi		
☒ Use InfoProvider Settings		
Near-Line Storage		
Use Near-Line Storage Accordi		
☒ Use InfoProvider Settings		

Variables

Definitions

Variable Description	Variable Name	Info-object	Selection Type	Required	Description /Explanation
Task list type	V_0PLAN_TYPE_0001	0PLAN_TYPE	Selection Option	No	
Material (Interval, Optional)	V_C_MATNR2_0002	C_MATNR2	Interval	No	
Equipment	V_C_EQUIPMT_0001	C_EQUIPMT	Selection Option	No	
Group Counter	V_C_PLNAL2_0001	C_PLNAL2	Selection Option	No	
Task list group (Select. option, Optional)	V_0PLNNR_0001	0PLNNR	Selection Option	No	
Inspection Date	V_0CALDAY_0007	0CALDAY	Interval	No	
Inspection Lot (Single value, Optional)	V_0INSP_LOT_0002	0INSP_LOT	Single value	No	
Plant (Authorization with input select option)	V_C_PLANT_0012	C_PLANT	Authorization with input select option	Yes	

Variable Sequence

Variable Sequence

	[V_0PLAN_TYPE_0001] Task list type
	[V_C_MATNR2_0002] Material (Interval, Optional)
	[V_C_EQUIPMT_0001] Equipment
	[V_C_PLNAL2] Group Counter
	[V_0PLNNR_0001] Task list group (Select. option, Optional)
	[V_0CALDAY_0007] Inspection Date
	[V_0INSP_LOT_0002] Inspection Lot (Single value, Optional)
	[V_C_PLANT_0012] Plant (Authorization with input select option)

Filters

Object	Filter Value	Explanation
C_DETAILE	= #	
C_LREC	= X	

Key figures

Description	Object	Calculation rule detail	Text Replacement variable	Display	Currency Conversion	Unit Conversion
No. of values	0NO_OF_VALS	Standard Key Figure	N/A	Default	N/A	N/A
Samples O.K.	0SAMPS_OK	Standard Key Figure	N/A	Default	N/A	N/A
Rejected samples	0SAMPS_BAD	Standard Key Figure	N/A	Default	N/A	N/A
Sum single vals	0SUM_OF_X	Standard Key Figure	N/A	Number of Decimal Places: 0.0000	N/A	N/A
Lower tol. limit	0LWR_LIMIT	Standard Key Figure	N/A	Number of Decimal Places: 0.0000	N/A	N/A
Upper tol. limit	0UPPR_LIMIT	Standard Key Figure	N/A	Number of Decimal Places: 0.0000	N/A	N/A

Characteristics

Location	Position	Info-object Name	Info-object Text	Explanation (if needed)
Row	1	0PLNNR	Task list group	
Free		C_MATNR2	Material	
Row	2	C_PLANNOD	Node Operation	
Free		C_EQUIPMT	Equipment	
Row	3	C_CHARTXT	Insp. Charact. Text	
Free		0PMTVERSION	Insp. Meth. Version	
Row	6	0BATCH	Batch	
Row	4	0CALDAY	Calendar Day	
Row	5	0INSP_LOT	Inspection Lot	
Free		0PPLANT	Plant of Insp. Meth.	
Free		C_PMETHOD	Inspection Method	
Free		C_INSP_CH	Insp. Charact. Numb	
Free		C_DETALLE	Number of the Ind.	
Free		C_LREC	Last Record	
Free		C_PLNAL2	Group counter	
Row	9	C_RESULT	Result	
Row	8	0ICHAR_UOM	Unit of measurement	
Free		0LOGSYS	Source System	
Row	7	0INSP_LOT__C_BATCH2	Batch	
Free		0INSP_LOT__C_MATNR2	Material	
Free		0INFOPROV	InfoProvider	

Cells

Conditions

Condition Name	Active By default	Key Figure (Structure)	Operator	Value	Characteristic Assignment
----------------	----------------------	---------------------------	----------	-------	---------------------------

Exceptions

Exception Name	Active By default	Alert Level	Operator	Value	Other parameters (if different from default)
	Yes/No				